

ROL-S		k			
		160	200	250	315
Säätöasento Injusteringsläge Adjustment settings	4,5	33	49	90	167
	4	29	42	76,5	137
	3,5	24	33	59,5	110
	3	20	27	47,3	88
	2,5	16	21	38	71
	2	13,2	17,2	31,4	55
	1,5	10,4	13,9	26	44
	1	8,4	10,6	21,3	35
	0,5	6,5	8,2	16,8	27
	0	4,9	5,6	14	21

Säätösuunta • Adjustment direction • Rotationsriktningen

